

Oxford Serial or Parallel Card

Installation Guide

This guide contains installation instructions for the following operating systems:

1. [Windows](#)

To install the driver:

Before you install the device, make sure that your operating system is current (for example, the most recent service pack is installed).

1. Right-click the zip folder that you downloaded, click **Extract All**, and complete the instructions.
2. Press the **Windows** key + **R**, type **devmgmt.msc**, and press **Enter** to open the Device Manager.
3. Right-click **PCI Serial Port**, which will have a "!" or "?" next to it to indicate a driver issue.
4. Click **Update Driver**.
5. Click **Browse my computer for driver software**.
6. Select the **Let me pick from a list of device drivers on my computer** option.
7. On the **Select your device's type from the list below** screen, click **Show All Devices**, and click **Next**.

Note: The **Select your device's type from the list below** screen does not appear on all systems. If you do not see this screen, skip this step.

Select the **Have Disk** option.

Browse to the **Windows** folder, select the folder for your operating system, and open the **32-bit** or the **64-bit** folder, depending on your system type.

Note: To view your system type, click **Start**. Right-click **Computer**, and then click **Properties**.

Oxford Serial or Parallel Card

Installation for Windows

Install Guide

Click the **OxMf** or **OxPCIeMf** file. Click **OK**, and then click **Next**.

Note: If you are using a serial card that uses the OxPCIeMf file and installation fails, repeat steps 4 to 9, then browse to the **Windows** folder. Browse to the **Serial Port Driver** folder and click the **oxserleg** file. Click **OK**, and then click **Next**.